

Advanced Computer Vision Week 04

Sep. 20, 2022 Seokju Lee





Camera Calibration

Camera Calibration: Review

- Process of estimating the **parameters** of a pinhole camera model.
- Determines which incoming light (3D) is associated with each pixel on the resulting **image (2D)**.
- In an ideal pinhole camera, a simple projection matrix is enough to do this.
- The camera projection matrix is derived from the **intrinsic** and **extrinsic** parameters of the camera.

$$\mathbf{s} \begin{bmatrix} \mathbf{x} \\ \mathbf{y} \\ 1 \end{bmatrix} = \begin{bmatrix} \mathbf{f}_x & \text{skew_c} \mathbf{f}_x & \mathbf{c}_x \\ \mathbf{0} & \mathbf{f}_y & \mathbf{c}_y \\ \mathbf{0} & \mathbf{0} & 1 \end{bmatrix} \begin{bmatrix} \mathbf{r}_{11} & \mathbf{r}_{12} & \mathbf{r}_{13} & \mathbf{t}_1 \\ \mathbf{r}_{21} & \mathbf{r}_{22} & \mathbf{r}_{23} & \mathbf{t}_2 \\ \mathbf{r}_{31} & \mathbf{r}_{32} & \mathbf{r}_{33} & \mathbf{t}_3 \end{bmatrix} \begin{bmatrix} \mathbf{X} \\ \mathbf{Y} \\ \mathbf{Z} \\ 1 \end{bmatrix}$$
• (X, Y, Z) : 3D point in the world coordinate
• $[R|t]$: extrinsic parameters to convert the world coordinate
• K : intrinsic parameters to represent the camera characteristics

$$= K[R|t] \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

- camera characteristics
- K[R|t]: camera projection matrix
- (x, y): 2D pixel location in the image plane
- s: scale factor

Camera Calibration: Optimization

$$\mathbf{x} = K[R|t]\mathbf{X} = M\mathbf{X}$$

 \rightarrow For each corresponding point *i* in the image:

$$\begin{bmatrix} u^{(i)} \\ v^{(i)} \\ 1 \end{bmatrix} \equiv \begin{bmatrix} p_{11} & p_{12} & p_{13} & p_{14} \\ p_{21} & p_{22} & p_{23} & p_{24} \\ p_{31} & p_{32} & p_{33} & p_{34} \end{bmatrix} \begin{bmatrix} x_w^{(i)} \\ y_w^{(i)} \\ z_w^{(i)} \\ 1 \end{bmatrix}$$

$$u^{(i)} = \frac{p_{11}x_w^{(i)} + p_{12}y_w^{(i)} + p_{13}z_w^{(i)} + p_{14}}{p_{31}x_w^{(i)} + p_{32}y_w^{(i)} + p_{33}z_w^{(i)} + p_{34}}$$

$$v^{(i)} = \frac{p_{21}x_w^{(i)} + p_{22}y_w^{(i)} + p_{23}z_w^{(i)} + p_{24}}{p_{31}x_w^{(i)} + p_{32}y_w^{(i)} + p_{33}z_w^{(i)} + p_{34}}$$

→ Expanding the matrix as linear equations

Camera Calibration: Optimization


→ Rearranging the terms:

| $\left[x_w^{(1)}\right]$ | $y_w^{(1)}$ | $z_w^{(1)}$ | 1 | 0 | 0 | 0 | 0 | $-u_1 x_w^{(1)}$ | $-u_1 y_w^{(1)}$ | $-u_1 z_w^{(1)}$ | $-u_1$ |
|--------------------------|-------------|-------------|---|-------------|-------------|-------------|---|------------------|--------------------------|------------------|--------|
| 0 | 0 | 0 | 0 | $x_w^{(1)}$ | $y_w^{(1)}$ | $z_w^{(1)}$ | 1 | $-v_1x_w^{(1)}$ | $-v_1y_w^{(1)}$ \vdots | $-v_1 z_w^{(1)}$ | $-v_1$ |
| : | : | : | : | : | : | : | : | : | | | : |
| $x_w^{(i)}$ | $y_w^{(i)}$ | $z_w^{(i)}$ | 1 | 0 | 0 | 0 | 0 | $-u_i x_w^{(i)}$ | $-u_i y_w^{(i)}$ | $-u_i z_w^{(i)}$ | $-u_i$ |
| 0 | 0 | 0 | 0 | $x_w^{(i)}$ | $y_w^{(i)}$ | $Z_W^{(i)}$ | 1 | $-v_i x_w^{(i)}$ | $-v_i y_w^{(i)}$ | $-v_i z_w^{(i)}$ | $-v_i$ |
| : | : | : | : | : | : | : | | | | | |
| $x_w^{(n)}$ | $y_w^{(n)}$ | $Z_W^{(n)}$ | 1 | 0 | 0 | 0 | 0 | $-u_n x_w^{(n)}$ | $-u_n y_w^{(n)}$ | $-u_n z_w^{(n)}$ | $-u_n$ |
| Lo | 0 | 0 | 0 | $x_w^{(n)}$ | $y_w^{(n)}$ | $z_w^{(n)}$ | 1 | $-v_n x_w^{(n)}$ | $-v_n y_w^{(n)}$ | $-v_n z_w^{(n)}$ | $-v_n$ |

 \rightarrow Solve for **p**:

$$A\mathbf{p} = 0$$

Known



 p_{11}

 p_{13}

 p_{21}

 p_{22}

 p_{23}

 p_{24}

 p_{31}


 p_{32}

 p_{33}

Camera Calibration: Least Squares Method

$$\mathbf{x} = K[R|t]\mathbf{X} = M\mathbf{X} \rightarrow \mathbf{y} = mx + b$$

$$(\mathbf{X_i}, \mathbf{x_i}) \rightarrow (x_i, y_i)$$



- ✓ Data: $(x_1, y_1), ..., (x_n, y_n)$
- ✓ Find (m, b) to minimize!

$$E = \sum_{i=1}^{n} (y_i - mx_i - b)^2$$

Camera Calibration: Least Squares Method


- ✓ Data: $(x_1, y_1), ..., (x_n, y_n)$
- \checkmark Find (m,b) to minimize!

$$E = \sum_{i=1}^{n} (y_i - mx_i - b)^2$$

$$E = \sum_{i=1}^{n} \left(\begin{bmatrix} x_i & 1 \end{bmatrix} \begin{bmatrix} m \\ b \end{bmatrix} - y_i \right)^2 = \begin{bmatrix} x_1 & 1 \\ \Box & \Box \\ x_n & 1 \end{bmatrix} \begin{bmatrix} m \\ b \end{bmatrix} - \begin{bmatrix} y_1 \\ \Box \\ y_n \end{bmatrix}^2 = \|\mathbf{A}\mathbf{p} - \mathbf{y}\|^2$$

$$= \mathbf{y}^T \mathbf{y} - 2(\mathbf{A}\mathbf{p})^T \mathbf{y} + (\mathbf{A}\mathbf{p})^T (\mathbf{A}\mathbf{p})$$

$$\frac{dE}{dp} = 2\mathbf{A}^T \mathbf{A} \mathbf{p} - 2\mathbf{A}^T \mathbf{y} = 0$$



→ Closed form solution!

$$\mathbf{A}^T \mathbf{A} \mathbf{p} = \mathbf{A}^T \mathbf{y} \Longrightarrow \mathbf{p} = (\mathbf{A}^T \mathbf{A})^{-1} \mathbf{A}^T \mathbf{y}$$

Camera Lens Distortion → **Undistortion**

✓ Correction of the image distortion.



Radial distortion model

$$x_{\text{corrected}} = x(1 + k_1r^2 + k_2r^4 + k_3r^6)$$

 $y_{\text{corrected}} = y(1 + k_1r^2 + k_2r^4 + k_3r^6)$

Tangential distortion model


→ caused by **unparallel** *lens* and *image plane*!


$$x_{\text{corrected}} = x + \left[2p_1 xy + p_2 (r^2 + 2x^2) \right]$$

 $y_{\text{corrected}} = y + \left[p_1 (r^2 + 2y^2) + 2p_2 xy \right]$











$$\begin{bmatrix} x_d \\ y_d \end{bmatrix} = \begin{bmatrix} x_u \\ y_u \end{bmatrix} + (k_1 r^2 + k_2 r^4 + k_3 r^6 + \cdots) \begin{bmatrix} x_u \\ y_u \end{bmatrix} + \begin{bmatrix} 2p_1 x_u y_u + p_2 (r^2 + 2x_u^2) \\ p_1 (r^2 + 2y_u^2) + 2p_2 x_u y_u \end{bmatrix},$$

Let's Try Camera Calibration!

✓ Camera Calibration Toolbox [1]

Camera calibration code is available at: https://view.kentech.ac.kr/1d2a3167-672f-4456-a5b8-b8c56c15eefe






Calibration results after optimization (with uncertainties):


Note: The numerical errors are approximately three times the standard deviations (for reference).

Try with Your Mobile Phone

✓ Calibrate different camera modes (e.g., different lens)








(0.5x) Wide-angle lens

(2x) Telephoto lens

[Q] What happens to the focal length?

Discussion: Dolly Zoom Effect

✓ How to film this video?



rag & bone films

Discussion: Dolly Zoom Effect

✓ A visual effect that zooms out of an object while moving towards it.



Focal Length: 300mm

Focal Length: 14mm

[Q] How to remove the blurry effects?

[Q] How to control the depth-of-field?

[Q] What happens to the focal length?

